



Entertain LED Speaker Light
S83WGW S83WGW-SHPR



PL-0246

CONGRATULATIONS!

You've purchased the finest in natural lighting technology with your new OttLite® product.

PRODUCT REGISTRATION FORM

Please complete the enclosed Product Registration Form and return it today by mail, or register online by going to: OttLite.com/warranty

WARNING: To prevent electric shock, make sure the lamp is not plugged in until all steps are complete.

NOTE: THIS UNIT IS FULLY ASSEMBLED

1. Remove from packing, placing product flat on a steady surface.
2. Connect power adapter input (A) into connector (B) in the rear-bottom of the speaker base.
Note: Only use with the supplied power adapter to avoid damage or fire.
3. Plug the power adapter (C) into a standard household 120V AC outlet.
Note: Only use with the supplied power adapter to avoid damage or fire.
4. To turn on lamp tap ☼ on top of shade.
5. To adjust brightness, tap ☼ again. The lamp has three levels of brightness.
6. To change color temperature of the light, touch and hold ☼. The lamp has three color modes.
7. By holding the fabric covered base you can lift the lamp shade off and use it as a battery powered light.

Note: The lamp is battery powered and needs to be charged on the speaker base. The lamp has an indicator that illuminates when the lamp is charging.

Bluetooth® Speaker Operation

1. To turn on the Bluetooth® speaker, press and hold ▶|| until blue light starts flashing.
2. On your device, open the Bluetooth® app or Bluetooth® settings. Locate and select the device "PL-0246" to pair the speaker to your device. A solid blue light indicates the speaker is connected. A flashing light indicates it is not connected.
3. Volume up/down, play/pause, and skip forward/backward can be controlled from either your device or the speaker itself.
4. To skip to forward, press and hold the volume up (+) button. To skip backward, press and hold the volume down (-) button.
5. To turn off the Bluetooth® speaker, press and hold ▶|| until the blue light starts flashing and the Bluetooth® speaker will turn off.

Note: The speaker must be plugged into a household outlet to play music and/or to recharge the lamp.

SAFETY WARNING: TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

1. Never use with an extension cord unless the plug can be fully inserted into the receptacles in the extension cord.
2. Do not alter the plug.
3. The lamp head included with this unit cannot be replaced by the consumer.
4. INDOOR USE ONLY.

NOTE: The important safety instructions appearing in this instruction sheet are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution, and care must be used with any electrical product.

CAUTION! IF THE EXTERNAL FLEXIBLE CABLE OR CORD OF THIS LUMINAIRE IS DAMAGED, IT SHALL BE EXCLUSIVELY REPLACED BY THE MANUFACTURER OR ITS SERVICE AGENT OR A SIMILAR QUALIFIED PERSON IN ORDER TO AVOID A HAZARD. INDOOR USE ONLY.

CAUTION! THE LIGHT SOURCE OF THIS LUMINAIRE IS NOT REPLACEABLE; WHEN THE LIGHT SOURCE REACHES ITS END OF LIFE THE WHOLE LUMINAIRE SHALL BE REPLACED.

CAUTION: Any change or modification to product not expressly recognized by OttLite Technologies voids OttLite's responsibility for proper function of product.

FCC PART 15

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that the interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

CAN ICES-005 (B)/NMB-005 (B)

POWER ADAPTER SPECIFICATION:

Input: AC 100-240V, 50/60 Hz, 0.6A
Output: 5V DC, 2.0A with a Micro USB Connector

Output power: 6W (LED light) + 3W (speaker)

Speaker: 1.5 inch (40mm), 4 ohms

Bluetooth® v.5.0

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by OttLite® is under license.

IC WARNING

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

Cet appareil est conforme aux CNR exempts de licence d'Industrie Canada. Le fonctionnement est soumis aux deux conditions suivantes:

- (1) Cet dispositif ne peut causer des interférences; et
- (2) Cet appareil doit accepter toute interférence, y compris les interférences qui peuvent causer un mauvais fonctionnement de l'appareil.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre le radiateur et votre corps.